



Appendix L: DFV History Downloader

- 1) Download "Liquip DFV History Download" program from Liquip website and install on Windows
- 2) Connect DFV to PC (DFV port previously configured as "Touch PC" 9600).


Select the PC com port in the application, default baud rate of 9600. Press "Connect..."



- 3) Select the Meter Number (Check meter number on docket printout, usually "0000" or "0001"). Press "Start".



- 4) Watch the data load (the full log of 4000 items takes about 10 minutes). If you want, press "Stop" earlier, when the date you're interested in has passed.



- 5) Press "Save..." to select a file location and filename.



- 6) Excel will open up the saved DFV file. (Adjust column widths to view the data).

	A	B	C	D	E	F	G	H
1	Date	Time	Event	Product/Compartment	Uncompensated volume/level	compensated v	Temperatu	units.
2	4/03/2016	12:47:17	Printed and Reset					
3	29/02/2016	16:28:55	Printed and Reset					
4	29/02/2016	15:42:49	Flow	DIESEL	3860	3910	25.5	C
5	29/02/2016	15:42:49	Printed and Reset					
6	29/02/2016	15:42:47	Level	0	315			
7	29/02/2016	15:39:56	Flow	DIESEL	2004	2030	25.5	C
8	29/02/2016	15:39:56	Printed and Reset					
9	29/02/2016	15:38:32	Printed and Reset					
10	29/02/2016	15:37:16	Level	0	391			